

**SOLID STATE
SUPPLIES**

**MF833V
USB Modem
Quick Start Guide**

Solid State Supplies Ltd
+44 (0)1527 830800 | sales@sssltd.com | www.sssltd.com

LEGAL INFORMATION

Copyright © 2018 ZTE CORPORATION.

All rights reserved.

No part of this publication may be excerpted, reproduced, translated or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written permission of ZTE Corporation.

The manual is published by ZTE Corporation. We reserve the right to make modifications on print errors or update specifications without prior notice.

Version No. : R1.0


Edition Time: February 2, 2018

Getting to Know Your Modem

Your modem supports data service through the mobile phone network.

The following figure is only for your reference. The actual product may be different.

1. Modem cap
2. Front cover
3. Indicator light
4. USB connector
5. micro-SIM card slot



Installing the micro-SIM Card

1. Press and push the front cover and remove it.



 **NOTE:**

Open the front cover carefully. Failing to do so may cause damage to the front cover.


2. Insert a micro-SIM card to the micro-SIM card slot.

 **WARNING!**

Your modem does not support SIM cards and nano-SIM cards. To avoid damage to the modem, do not use those cards or any card holders.



3. Slide the front cover gently back into place.



Connecting the Modem to Your Device

Insert the modem into your device's USB port securely. After the MF833V is connected to the device successfully, your device can access the Internet.

Status Indicator Light

Color	Description
No light	Airplane/Standby mode
Red solid	Booting up, searching for a network, no micro-SIM card, or no network service.
Green solid	Registered to a 2G/3G mobile network.
Green blinking	Connected to the 2G/3G mobile network and data is being transferred.
Blue solid	Registered to a 4G mobile network.
Blue blinking	Connected to the 4G mobile network and data is being transferred.

Warning and Notice

Using Your Modem

- If inadequately shielded, some electronic devices may be affected by the electromagnetic interference caused by the modem, such as the electronic system of vehicles. Consult the manufacturers of such devices before using the modem if necessary.
- Operating the modem may interfere with medical devices such as hearing aids and pacemakers. Always keep the modem more than 20 centimeters away from such medical devices when your modem is turned on. Turn the modem off if necessary. Consult a physician or the manufacturers of medical devices before using the modem if necessary.
- Be aware of the usage limitation when using the modem at places such as oil warehouses or chemical factories, where there are explosive gases or explosive products being processed. Turn off the modem if necessary.

- Do not use electronic transmission devices in aircrafts, at petrol stations or in hospitals. Observe and obey all warning signs, and turn off the modem in these conditions.
- Do not touch the inner antenna area unless it is necessary. Otherwise the performance of the modem may be affected.
- Keep the modem out of the reach of children to prevent injury.
- When the modem is operating, do not touch the metallic parts. Failing to do so may cause burns.
- Use original accessories or accessories that are authorized. Using any unauthorized accessories may affect the performance of the modem and violate the related national regulations about telecom terminals.
- Avoid using the modem near or inside metallic structures or establishments that can emit electromagnetic waves, because signal reception may be affected.

- The modem is not waterproof. Keep the modem dry and store it in a shady and cool place.
- Do not use the modem immediately after a sudden temperature change. In such case, dew may be generated inside and outside the modem, so do not use it until it becomes dry.
- Handle the modem carefully. Do not drop, bend or strike it. Otherwise the modem may be damaged.
- Only qualified personnel can dismantle and repair the modem.
- An operating temperature between -10°C and +55°C and a humidity between 5% and 95% are recommended.

Limited Warranty

- This warranty does not apply to defects or errors in the product caused by:
 - i. Reasonable abrasion.
 - ii. End users' failure to follow ZTE's installation, operation or maintenance instructions or procedures.

- iii. End users' mishandling, misuse, negligence, or improper installation, disassembly, storage, servicing or operation of the product.
- iv. Modifications or repairs not provided by ZTE or a ZTE-certified individual.
- v. Power failures, surges, fire, flood, accidents, and actions of third parties or other events outside ZTE's reasonable control.
- vi. Usage of third-party products, or usage in conjunction with third-party products if such defects are due to the combined usage.
- vii. Any other cause beyond the range of normal usage intended for the product.

End users have no right to reject or return the product, or receive a refund for the product from ZTE under the above-mentioned situations.

- This warranty is end users' sole remedy and ZTE's sole liability for defective or nonconforming items, and is in lieu of all other warranties, expressed, implied or statutory, including but not limited to the implied warranties of merchantability and fitness for a particular purpose, unless otherwise required under the mandatory provisions of the law.

Limitation of Liability

ZTE shall not be liable for any loss of profits or indirect, special, incidental or consequential damages resulting from or arising out of or in connection with using of this product, no matter whether or not ZTE had been advised, knew or should have known of the possibility of such damages, including, but not limited to lost profits, interruption of business, cost of capital, cost of substitute facilities or product, or any downtime cost.